


RIVO MULTITRADE OPTICAL SYSTEMS

How to view the core switch configuration



Overview

8 Steps to configure your network switch If everything checks out, power on the switch and verify that all the indicator lights are in working order. Next.

Key Takeaways

You can view a core switch's configuration using commands like `show running-config` for the active configuration and `show startup-config` for the saved configuration. Accessing the Switch

To view the configuration, first connect to the switch via console cable, SSH, or Telnet. Use a terminal emulator like PuTTY and log in with the appropriate credentials. Ensure you have privileged EXEC mode access (enable mode) to run configuration commands .

Key Commands to View Configuration

- `show running-config`: Displays the current active configuration in RAM, including VLANs, interface settings, and security parameters .
- `show startup-config`: Shows the configuration stored in NVRAM that will load on the next reboot .
- `show version`: Provides switch model, IOS version, uptime, and memory information .
- `show vlan brief`: Lists all VLANs configured on the switch and their status .

- show interfaces / show ip interface brief: Displays interface status, IP addresses, and operational state .
- show mac address-table: Shows learned MAC addresses and associated ports .
- show spanning-tree: Displays STP status to prevent network loops .
- show inventory / show environment: Checks hardware components, power supplies, and environmental health .

Additional Tips

- Use context-sensitive help by typing ? after a command to see available options .
- For VLAN-specific details, use show vlan id or show interfaces trunk to verify trunking.
- To ensure changes are saved, compare running-config with startup-config and use copy running-config startup-config if needed . By systematically using these commands, you can fully inspect the core switch's configuration, verify VLANs, interface settings, and security policies, and ensure the switch is operating as intended .

Article Content

8 Steps to configure your network switch

If everything checks out, power on the switch and verify that all the indicator lights are in working order. Next, use a rollover cable to

Related Video Reference

This video was associated with the source search result. Verify technical details against current product documentation and project requirements.

Contact Us

Continue your research online:

Website: <https://rivomultitrade.co.za>

Technical inquiry: <https://rivomultitrade.co.za/contact.html>

This document is for preliminary research. Verify specifications against current standards, product documentation and project requirements.

